

Mounting instructions for

*CoBrite*_{DX4}

Into CBDX4-19-x

19 inch rack mount adaptor

E-Mail: info@id-photonics.com


www.id-photonics.com



ID Photonics GmbH, Neubiberg, Germany

V1.0

- 1 Remove Side holders and cramps at edge from Tray holder using a Hex Driver (2.5mm)



- 2 Remove plastic caps from both sides of laser handle using a small screwdriver



- 3 Remove plastic caps at lower rear end of laser chassis using a small screw driver




- 4 Detach laser chassis handle by removing screw inside handle hole using an appropriate screwdriver




5 Reuse Handle screw to fix side holders onto laser chassis into center thread



- 6 Slide Laser chassis into Tray so that laser chassis faceplate protrudes through faceplate of adaptor tray



- 7 Fix laser chassis by screwing cramps and side holders to tray





8 Done! ;-)